

Tailgate Protection Installation Instructions Read Carefully before Installing

Section A Tailgate protector installation.

- 1. Clean the tailgate surface completely of all dirt and debris before beginning.
- 2. Position the tailgate protector on the tailgate. Once the tailgate protector is in the desired location, pull the corner of the tailgate protector down and drill (1) 1/8" hole thru the tailgate protector and the tailgate. Repeat on the opposite end. Then drill (2) 1/8" holes spaced equally from the center) thru the tailgate protector and the tailgate.
- 3. Then remove the tailgate protector and enlarge the holes in the protector to 3/16" for screw clearance. (Some applications will have 3/16" holes already in the tailgate protector, if so use these as guides when drilling.) Then reinstall the tailgate protector with the #8 stainless steel screws provided in the bolt pack. See illustration A.

(NOTE: Use caution when installing #8 stainless steel screws.)

Section B One piece full tailgate protector

- Position the full tailgate protector on the tailgate. Once the full tailgate
 protector is in the desired location drill (8) 1/8" holes (4 in the corners and 4
 equally spaced from the center thru the tailgate protector and the tailgate.
 (Some models may have crown on the tailgate, if so pull the corners down as
 far as possible without bowing the protector before drilling.)
- 2. Then remove the full tailgate protector and enlarge the holes in the protector to 3/16" for screw clearance. (Some applications will have 3/16" holes already in the full tailgate protector, if so use these as guides when drilling.)Then reinstall the full tailgate protector with the #8 stainless steel screws provided in the bolt pack. See illustration A.

Section C Full tailgate plate installation.

- Place the full tailgate plate on the tailgate and drill (8) 1/8" holes (4 in the corners and 4 equally spaced from the center) thru the full tailgate plate and the tailgate. Make sure when drilling holes that you drill into a surface that is flush with the under side of the tailgate plate.
- Then remove the full tailgate plate and enlarge the holes in the plate to 3/16" for screw clearance. Then fasten the full tailgate plate to tailgate with the (8) #8 stainless steel screws provided in the bolt pack. See illustration B.
- 3. For rust prevention a small amount of silicone can be added to the screw holes before installing the screw.

PART	DESCRIPTION		1 PC FULL TAILGATE	her as early a same of wearences and and and
	DESCRIPTION	PROTECTOR	PROTECTOR	PROTECTOR
Tailgate protector	tailgate protector	1		1
Full tailgate protector	full tailgate protector		1	
Full tailgate plate	tailgate plate			1
T-bolt	bolt pack	1		1
F-bolt	bolt pack		1	1
000011CC	warranty card	1	1	1

Illustration A
Tailgate protector installation











